

Make	Year	Model	Headlight	Notes
Acura	1997-02	CL	Separate high beam with 2 wire connector. Tap each wire.	
Acura	1986-89	Integra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	1990-93	Integra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	1994-01	Integra	Separate high beam with 2 wire connector. Tap each wire.	
Acura	1986-88	Legend	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	1989-95	Legend	Separate high beam with 2 wire connector. Tap each wire.	
Acura	1989-90	Legend Coupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	2001-02	MDX	Separate high beam with 2 wire connector. Tap each wire.	
Acura	1991-02	NSX	Separate high beam with 2 wire connector. Tap each wire.	
Acura	1996-98	RL	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	1998-02	RL	Separate high beam with 2 wire connector. Tap each wire	
Acura	2002-	RSX	Separate high beam with 2 wire connector. Tap each wire	
Acura	1996-99	SLX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	1995-98	TL	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Acura	1999-02	TL	Separate high beam with 2 wire connector. Tap each wire.	
Acura	1992-94	Vigor	Separate high beam with 2 wire connector. Tap each wire.	
Alfa Romeo	1991-95	164	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1975-80	Alfetta		
	1967-74	GTV	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-86	GTV-6		
	1988-91	Milano	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1967-69	Spider	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1971-94	Spider	Single high/low with 3 wire connector. Tap the 2 outside wires.	
AM General	1992-01	Hummer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002-2003-	Hummer H1 H2	Single high/low with 3 wire connector. Tap the 2 outside wires.	
AMC		All Models		
Aston Martin		All Models		
Audi	1988-92	80 & 90	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-95	90	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-94	100	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-92	200	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	4000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-88	5000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	A4	Separate high beam with 2 wire connector. Tap each wire.	
	1995-early 98	A6	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	A6	Separate high beam with 2 wire connector. Tap each wire.	
	1997-99	A8	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	A8	Separate high beam with 2 wire connector. Tap each wire.	
	2001-2002	Allroad Quattro		
	1994-98	Cabriolet	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Coupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1990-92	Coupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	S4	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	S4	Separate high beam with 2 wire connector. Tap each wire.	
	1995-97	S6	Separate high beam with 2 wire connector. Tap each wire.	
	2002	S6 Avant	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	S8	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	TT	Separate high beam with 2 wire connector. Tap each wire. Drivers side is white w/black trace and brown. Passenger side is white and brown. (2001 w/Xenons)	
	1990-94	V-8 Sedan	Separate high beam with 2 wire connector. Tap each wire.	
	1980-85	Most Models	Separate high beam with 2 wire connector. Tap each wire.	
Austin		All Models		
Austin Healey		All Models		
Bentley		All Models		
BMW	1968-75	2002	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1976-83	320i	Separate high beam with 2 wire connector. Tap each wire.	
	1984-89	318i, 325e, 325i	Separate high beam with 2 wire connector. Tap each wire.	
	1990-91	3-series	Separate high beam with 2 wire connector. Tap each wire.	
	1992-99	3-series	Separate high beam with 2 wire connector. Tap each wire.	
	1996	318iS	Separate high beam with 2 wire connector. Tap each wire.	
	1999	323i & 328i	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1999-02	3-series	Separate high beam with 2 wire connector. Tap each wire.	
	1989-00	5-series	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	5-series	Separate high beam with 2 wire connector. Tap each wire.	
		6-series		
	1987-94	7-series	Separate high beam with 2 wire connector. Tap each wire.	
	1995-02	7-series	Separate high beam with 2 wire connector. Tap each wire.	
	1992-97	8-series	Separate high beam with 2 wire connector. Tap each wire.	
	1997-99	M-series	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	M3	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	M5	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	X-series	Separate high beam with 2 wire connector. Tap each wire.	
	1997-02	Z3	Separate high beam with 2 wire connector. Tap each wire.	
		Z4		
		Z8		
Buick	1989-02	Century	Separate high beam with 2 wire connector. Tap each wire.	
	1987-91	Electra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-88	LeSabre	Separate high beam with 2 wire connector. Tap each wire.	
	1990-02	LeSabre	Separate high beam with 2 wire connector. Tap each wire.	
	1988-91	Park Avenue	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Park Avenue	Separate high beam with 2 wire connector. Tap each wire.	
	1989-91	Reatta	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-02	Regal	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1988-99	Riviera	Separate high beam with 2 wire connector. Tap each wire.	
	1991-96	Roadmaster	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002-	Rendezvous	Separate high beam with 2 wire connector. Tap each wire.	
	1989-91	Skylark	Separate high beam with 2 wire connector. Tap each wire.	
Cadillac	1987-93	Allante	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-92	Brougham	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2005	CTS	Driver's side, unbolt the three 10mm bolts holding the airbox in place, unplug the airflow sensor and remove. Tap the green w/white wire and the thinner black wire (one in from the end of the connector).	
	1997-01	Catera	Separate high beam with 2 wire connector. Tap each wire.	
	1994-99	Concours	Separate high beam with 2 wire connector. Tap each wire.	
	1987-02	DeVille (DHS)	Separate high beam with 2 wire connector. Tap each wire.	00 - Remove shroud by pushing center pin and removing clips - P-side - Unbolt 2 bolts on top, one inside bottom and pull lamp to release nipple - attach to black & green wire
	1986-91	Eldorado	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Eldorado	Separate high beam with 2 wire connector. Tap each wire.	
	1999-00	Escalade	Separate high beam with 2 wire connector. Tap each wire.	
	2002	Escalade	Separate high beam with 2 wire connector. Tap each wire.	
	1987-96	Fleetwood	Separate high beam with 2 wire connector. Tap each wire.	
	1986-91	Seville	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1992-02	Seville	Separate high beam with 2 wire connector. Tap each wire.	02 - P-side - remove shroud - remove 2 bolts and swing lamp out to gain access
	1993	Sixty Special	Separate high beam with 2 wire connector. Tap each wire.	
Chevrolet	1985-02	Astro w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Astro w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	2002	Avalanche		
	1987-96	Beretta	Separate high beam with 2 wire connector. Tap each wire.	
		Bel Air/150/210		
	1982-94	Blazer w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991	Blazer w/4 Headlights	H4701	
	1983-94	Blazer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-97	Blazer w/Sealed Beam	H4666	
	1995-02	Blazer w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
		C-10		
	1982-92	Camaro	Separate high beam with 2 wire connector. Tap each wire.	
	1993-97	Camaro	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Camaro	Separate high beam with 2 wire connector. Tap each wire.	
	1991-96	Caprice	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-94	Cavalier	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-99	Cavalier	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	Cavalier	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1987-91	Celebrity	Separate high beam with 2 wire connector. Tap each wire.	
		Chevelle		
		Cheyenne		

Make	Year	Model	Headlight	Notes
	1987-96	Corsica Corvair	Separate high beam with 2 wire connector. Tap each wire.	
	1984-96	Corvette	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-02	Corvette El Camino Express G20 Van	Separate high beam with 2 wire connector. Tap each wire.	
	1995-96	Impala	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Impala	Separate high beam with 2 wire connector. Tap each wire.	
	1990-01	Lumina	Separate high beam with 2 wire connector. Tap each wire.	
	1990-96	Lumina Van	Separate high beam with 2 wire connector. Tap each wire.	
	1997-02	Malibu	Separate high beam with 2 wire connector. Tap each wire.	
	1995-02	Monte Carlo Nova	Separate high beam with 2 wire connector. Tap each wire.	
	1979-00	Pickup, Full Size, Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-00	Pickup, Full Size, Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1983-94	S-10	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-97	S-Series Pickup w/Sealed Beam	H4666	
	1994-2002	S-Series Pickup w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	Silverado	Separate high beam with 2 wire connector. Tap each wire.	
	1982-99	Suburban w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991	Suburban w/4 Headlights	H4701	
	1992-02	Suburban w/Composite	Separate high beam with 2 wire connector. Tap each wire.	02 - Has F2P & separate hi beam - 2 wire - pull pin headlight removal - under cover install
	1995-99	Tahoe w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1995-02	Tahoe w/Composite Tracker	Separate high beam with 2 wire connector. Tap each wire.	
	2002	Trailblazer	Separate high beam with 2 wire connector. Tap each wire.	
	1978-02	Van w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	Van w/4 Headlights	Separate high beam with 2 wire connector. Tap each wire.	
	1992-96	Van w/4 Headlights	H4701	
	1996-02	Van Express w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1997-02	Venture	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Chrysler	1999-02	300M	Separate high beam with 2 wire connector. Tap each wire.	
	1995-00	Cirrus	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1993-97	Concorde	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1998-02	Concorde	Separate high beam with 2 wire connector. Tap each wire.	
	1981-83	Imperial	Separate high beam with 2 wire connector. Tap each wire.	
	1991-93	Imperial	H4701	
	1978-86	LeBaron	Separate high beam with 2 wire connector. Tap each wire.	
	1991-92	LeBaron 2 Door	Separate high beam with 2 wire connector. Tap each wire.	
	1993	LeBaron 2 Door	Separate high beam with 2 wire connector. Tap each wire.	
	1990-94	LeBaron 4 Door	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994	LeBaron Convertible	Separate high beam with 2 wire connector. Tap each wire.	
	1995	LeBaron	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1994-97	LHS	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1999-02	LHS	Separate high beam with 2 wire connector. Tap each wire.	
	1981	Newport	Separate high beam with 2 wire connector. Tap each wire.	
	1982-88	New Yorker	Separate high beam with 2 wire connector. Tap each wire.	
	1988-89	New Yorker Landau	Separate high beam with 2 wire connector. Tap each wire.	
	1990	New Yorker	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-92	New Yorker	Separate high beam with 2 wire connector. Tap each wire.	
	1993	New Yorker	H4701	
	1994-96	New Yorker	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
		Pacifica		
	2002	Prowler	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	PT Cruiser	Separate high beam with 2 wire connector. Tap each wire.	Remove access panel in wheel well to get to headlight
		Royal		
	1995-00	Sebring	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	Sebring Coupe	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1996-02	Sebring Convertible	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	00 - P-side - Disconnect harness from light*
	1989-91	TC	Separate high beam with 2 wire connector. Tap each wire.	
	1990-95	Town & Country	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-97	Town & Country	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	

Make	Year	Model	Headlight	Notes
	1998-00	Town & Country	Separate high beam with 2 wire connector. Tap each wire.	Separate hi beam - 2 wire - attach to foam on high pressure line under hood
	2001-02	Town & Country	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	03 - P-side - Remove 3 bolts on top of headlight to release headlight assembly*
Citroen		All Models		
Daewoo		Lanos		
		Leganza		
		Nubira		
Daihatsu	1989-92	Charade	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Delorean	1981-83	DMC-12	A 101315	
Dodge	1995-00	Avenger	Separate high beam with 2 wire connector. Tap each wire.	
	1987-95	Caravan	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-92	Caravan Cargo Van	H4666	
	1993-95	Caravan Cargo Van	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	Caravan	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
		Challenger		
		Charger		
	1981-88	Colt	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	Colt	Separate high beam with 2 wire connector. Tap each wire.	
	1992	Colt H/Back Exc. Canada	Separate high beam with 2 wire connector. Tap each wire.	
	1992	Colt H/Back Canada	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	Colt	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-88	Colt Vista	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1991	Colt Vista	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Coronet		
	1987-95	Dakota w/ Sealed Beam	H4666	
	1991-96	Dakota w/Composite	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-02	Dakota	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
		Dart		
	1987-91	Daytona	H4666	
	1992-93	Daytona	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Durango	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1988-93	Dynasty	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Grand Caravan		
	1993-97	Intrepid	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1998-02	Intrepid	Separate high beam with 2 wire connector. Tap each wire.	
		Lancer		
	1991-92	Monaco	Separate high beam with 2 wire connector. Tap each wire.	
	1995-02	Neon	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1983-93	Ram Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-01	Ram Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Ram Pickup 1500	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2002	Ram Pickup 2500, 3500	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-93	Ram 50	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1988-93	Ram Van, Wagon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-02	Ram Van, Wagon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-94	Shadow	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-96	Stealth	Separate high beam with 2 wire connector. Tap each wire.	
	1995-02	Stratus	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1989-95	Spirit	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-00	Viper	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	Viper		
Eagle	1988-89	Medallion	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-92	Premier	Separate high beam with 2 wire connector. Tap each wire.	
	1989-92	Summit	Separate high beam with 2 wire connector. Tap each wire.	
	1993-96	Summit	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-96	Summit Wagon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-91	Talon	H4666	
	1992-98	Talon	Separate high beam with 2 wire connector. Tap each wire.	
	1993-97	Vision	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
Ferrari	1985-90	328,308, Mondial	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-94	348, Mondial t	Separate high beam with 2 wire connector. Tap each wire.	
	1992-95	512 TR	Separate high beam with 2 wire connector. Tap each wire.	
	1991-93	F40	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1994-95	Spider	Separate high beam with 2 wire connector. Tap each wire.	
Fiat	1977-78	124 Sport	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1971-78	128	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-89	Bertone X1/9	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-79	Spyder	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-82	Strada	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1976-83	X 1/9	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Ford	1986-91	Aerostar	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-97	Aerostar	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1994-98	Aspire	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1969-78	Bronco	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-86	Bronco	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-91	Bronco	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-88	Bronco II	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-90	Bronco II	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-96	Bronco	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1995-00	Contour	Separate high beam with 2 wire connector. Tap each wire.	
	1979-84	Courier	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-84	Crown Victoria	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1987-91	Crown Victoria	Separate high beam with 2 wire connector. Tap each wire.	
	1992-97	Crown Victoria	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Crown Victoria	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1969-78	Econoline Van w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-02	Econoline Van w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Econoline Van w/Composite	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2001-02	Escape	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-85	Escort	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-96	Escort	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-02	Escort	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2001-02	Excursion	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	01
	1997-02	Expedition	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	03
	1991-94	Explorer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-01	Explorer	Single high/low with 3 wire connector. Looking at the light from the front of the	97 - Black & Green - P-side - lower front hole & over top for zip tie
	2002	Explorer	Separate high beam with 2 wire connector. Tap each wire.	02 - P- Side - Pull up tabs holding headlight in place - Remove headlight - Remove grill - attach TX to louvers - feed wires back and attach to 2 wires from separate high beam
	2002	Explorer Sport	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	

Make	Year	Model	Headlight	Notes
	2002	Explorer Sport Trac	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1982-85	EXP Fairlane	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-81	Fairmont	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-83	Fairmont Falcon	Separate high beam with 2 wire connector. Tap each wire.	
	1988-93	Festiva	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-80	Fiesta	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1969-79	F-100 - F-350	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-86	F-150, F-250, F-350	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-91	F-150, F-250, F-350	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	F-150, F-250, F-350	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1999-02	F Super Duty w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999	F Super Duty w/Composite	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1999-02	F-150 - F-550 w/ Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-02	F-250 - F550 w/Composite	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2000-02	Focus Galaxie	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-81	Granada	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982	Granada	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1977-79	LTD II	Separate high beam with 2 wire connector. Tap each wire.	
	1982-86	LTD	Separate high beam with 2 wire connector. Tap each wire.	
	1974-78	Mustang II	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-80	Mustang II	Separate high beam with 2 wire connector. Tap each wire.	
	1985-86	Mustang SVO	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-86	Mustang	Separate high beam with 2 wire connector. Tap each wire.	
	1987-93	Mustang	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-04	Mustang	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1972-78	Pinto	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-80	Pinto	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-92	Probe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-97	Probe	H4666	
		Ranchero		
	1983-88	Ranger	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-92	Ranger	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-02	Ranger	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1986-91	Taurus	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-02	Taurus	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1984-85	Tempo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-94	Tempo	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1977-79	Thunderbird	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980	Thunderbird	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981	Thunderbird	Separate high beam with 2 wire connector. Tap each wire.	
	1982	Thunderbird	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-86	Thunderbird	Separate high beam with 2 wire connector. Tap each wire.	
	1989-93	Thunderbird	Separate high beam with 2 wire connector. Tap each wire.	
	1994-97	Thunderbird	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2002	Thunderbird	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
		Torino		
	1995-02	Windstar	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
General Motors	1997-99	EV1	Separate high beam with 2 wire connector. Tap each wire.	
Geo	1989-97	Metro w/Sealed Beam	H4666	
	1989-94	Metro w/Composite	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-92	Prizm	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-97	Prizm	Separate high beam with 2 wire connector. Tap each wire.	
	1989	Spectrum	Single high/low with 3 wire connector. Tap the 2 outside wires.	S/B Chevrolet
	1991	Storm	H4701	
	1992-93	Storm	Separate high beam with 2 wire connector. Tap each wire.	
	1989-97	Tracker	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
GMC	1980-87	Caballero	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	Denali	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	Envoy	Separate high beam with 2 wire connector. Tap each wire.	
	1972-87	G Series Van	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	G Series Van w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	G Series Van w/4 Headlights	Separate high beam with 2 wire connector. Tap each wire.	
	1973-80	Jimmy	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-88	Jimmy	Separate high beam with 2 wire connector. Tap each wire.	
	1989-91	Jimmy w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	Jimmy w/4 Headlights	H4701	
	1993-94	Jimmy	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-97	Jimmy w/Sealed Beam	H4666	
	1995-01	Jimmy w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1973-78	Pickup, Full Size	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980	Pickup, Full Size	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-87	Pickup, Full Size	Separate high beam with 2 wire connector. Tap each wire.	
	1979-90	Pickup, Full Size w/Sealed Beam	H4701	
	1990-91	Pickup, Full Size w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	Pickup, 3500 w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Pickup, 3500 w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1992-96	Rally/Vandura w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-96	Rally/Vandura w/4 Headlights	H4701	
	1983-92	S-15/Jimmy	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1986-02	Safari w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Safari w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1996-02	Savana w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	Savana w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1988-91	Sierra w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	Sierra w/4 Headlights	H4701	
	1988-00	Sierra w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Sierra w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1992-93	Sonoma	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-97	Sonoma w/Sealed Beam	H4666	
	1994-02	Sonoma w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1973-80	Suburban	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-88	Suburban	Separate high beam with 2 wire connector. Tap each wire.	
	1989-91	Suburban w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	Suburban w/4 Headlights	H4701	
	1992-99	Suburban w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-00	Suburban w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1992	Syclone	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-93	Typhoon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-99	Yukon w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Yukon w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
Honda	1982-85	Accord	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1986-89	Accord	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-02	Accord	Separate high beam with 2 wire connector. Tap each wire.	
	1974-81	Civic	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-85	Civic	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-87	Civic	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	Civic	Separate high beam with 2 wire connector. Tap each wire.	
	1992-02	Civic	Single high/low with 3 wire connector. Tap the 2 outside wires.	01 & '04 - P-side - remove battery for access
	1984-85	CRX	H4666	
	1986-87	CRX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-92	CRX	Separate high beam with 2 wire connector. Tap each wire.	
	1997-02	CR-V	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1976-79	CVCC	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-97	Del Sol	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Insight	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Odyssey	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-99	Passport	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Passport	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-91	Prelude	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-96	Prelude	Separate high beam with 2 wire connector. Tap each wire.	
	1997-01	Prelude	Separate high beam with 2 wire connector. Tap each wire	
	2000-02	S2000	Separate high beam with 2 wire connector. Tap each wire	

Make	Year	Model	Headlight	Notes
Hyundai	1995-99	Accent	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Accent	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-95	Elantra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-98	Elantra	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1999-00	Elantra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Elantra	Separate high beam with 2 wire connector. Tap each wire	
	1986	Excel	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-94	Excel	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Santa Fe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-95	Scoupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-94	Sonata	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-98	Sonata	Separate high beam with 2 wire connector. Tap each wire.	
	1999-01	Sonata	Separate high beam with 2 wire connector. Tap each wire.	
	2002	Sonata	Separate high beam with 2 wire connector. Tap each wire	
	1997-99	Tiburon	Separate high beam with 2 wire connector. Tap each wire.	
2000-02	Tiburon	Separate high beam with 2 wire connector. Tap each wire		
2001-02	XG300, XG350	Separate high beam with 2 wire connector. Tap each wire		
Infiniti	1991-96	G20	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-00	G20	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	G35	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1996-99	I30	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-01	I30 w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	2000-01	I30 w/HID Headlights		
	2002	I35	Separate high beam with 2 wire connector. Tap each wire.	
	1993-97	J30	Separate high beam with 2 wire connector. Tap each wire.	
	1990-92	M30	Separate high beam with 2 wire connector. Tap each wire.	
	1990-96	Q45	Separate high beam with 2 wire connector. Tap each wire.	
	1997-98	Q45	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-02	Q45	Separate high beam with 2 wire connector. Tap each wire	
	1997-99	QX4	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000	QX4 w/Composite	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000	QX4 w/HID Headlight	Separate high beam with 2 wire connector. Tap each wire	
	2001-02	QX4	Separate high beam with 2 wire connector. Tap each wire.	
Isuzu	1989-94	Amigo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-99	Amigo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000	Amigo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Axiom	Separate high beam with 2 wire connector. Tap each wire.	
	1996-00	Hombre	Separate high beam with 2 wire connector. Tap each wire.	
	1981-86	I-Mark	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-91	I-Mark	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-88	Impulse	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1990-92	Impulse	Separate high beam with 2 wire connector. Tap each wire.	
	1996-00	Oasis	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-95	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-99	Rodeo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Rodeo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-93	Stylus	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-02	Trooper	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-86	Trooper II	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-90	Trooper II	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-01	Vehicross	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Jaguar	2000	S-type	Separate high beam with 2 wire connector. Tap each wire.	Separate hi beam - 2 wire - P-side - remove front cover & install TX underneath
	1995-97	Vanden Plas	Separate high beam with 2 wire connector. Tap each wire.	
	1998-01	Vanden Plas	Separate high beam with 2 wire connector. Tap each wire.	
	1990-97	XJ6	Separate high beam with 2 wire connector. Tap each wire.	
	1998-01	XJ8	Separate high beam with 2 wire connector. Tap each wire.	
	1994-96	XJ12	Separate high beam with 2 wire connector. Tap each wire.	
	1995-97	XJR	Separate high beam with 2 wire connector. Tap each wire.	
	1998-01	XJR	Separate high beam with 2 wire connector. Tap each wire.	
	1990-91	XJS	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-96	XJS	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1997-01	XK8	Separate high beam with 2 wire connector. Tap each wire.	
		XKE		
	1999-01	XKR	Separate high beam with 2 wire connector. Tap each wire.	
		X-type		
Jeep	1979-01	Cherokee	Single high/low with 3 wire connector. Tap the 2 outside wires.	96 - D - side - Remove side marker light (2 screws) and headlight surround (4 screws) - Remove bezel (4 screws) - pull light forward - fish TX wires from back & attach to black & either red - attach TX to harness
	1980-86	CJ	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-92	Comanche	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Commando		
	1993-98	Grand Cherokee	Single high/low with 3 wire connector. Tap the 2 outside wires.	97 - D-side - 3 wire - Black & red
	1999-02	Grand Cherokee	Separate high beam with 2 wire connector. Tap each wire.	00 & '04 - P side - Undo long center bolt - pull lamp out - 3 nipples hold it - 1 on outside, 2 inside, hi and low
	1985-91	Grand Wagoneer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993	Grand Wagoneer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Liberty	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1979-84	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Renegade		
	1982-86	Scrambler	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1969-78	Truck	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1969-79	Universal	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1969-78	Wagoneer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-84	Wagoneer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	Wagoneer	H4701	
	1987-95	Wrangler	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-02	Wrangler	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Kia	2003-	Cinco		
	2002	Optima	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Rio	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Sedona	Separate high beam with 2 wire connector. Tap each wire.	
	1994-97	Sephia	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-01	Sephia	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Spectra	Separate high beam with 2 wire connector. Tap each wire	
	1995-97	Sportage	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-02	Sportage	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2003-	Sorento	Check 4/26/06	
Lamborghini		All Models		
Lancia		All Models		
Land Rover	1993-97	Defender	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Discovery	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Freelander	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-94	Range Rover	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1996-02	Range Rover	Separate high beam with 2 wire connector. Tap each wire.	
Lexus	1990-91	ES250	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	ES300	Separate high beam with 2 wire connector. Tap each wire.	
	1993-02	GS300	Separate high beam with 2 wire connector. Tap each wire.	
	1998-00	GS400	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	GS430	Separate high beam with 2 wire connector. Tap each wire.	
	2002	IS300	Separate high beam with 2 wire connector. Tap each wire.	
	1992-00	SC300, SC400	Separate high beam with 2 wire connector. Tap each wire.	
	2002	SC430	Separate high beam with 2 wire connector. Tap each wire.	
	1990-92	LS400	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-00	LS400	Single high/low with 3 wire connector. Tap the 2 outside wires.	97 - D-Side - Remove access cover - separate hi below hi/lo - 2 wires - mount to battery hold down
	1996-97	LX450	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	LX470	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	RX300	Separate high beam with 2 wire connector. Tap each wire.	
Lincoln	2002	Blackwood	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1980-87	Continental	Separate high beam with 2 wire connector. Tap each wire.	
	1988-94	Continental	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Continental	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	

Make	Year	Model	Headlight	Notes
	2001-02	LS	Separate high beam with 2 wire connector. Tap each wire.	Remove 4 "screws" and shroud - separate hi beam - 2 wires - mount to hood release cable
	1982-83	Mark VI	Separate high beam with 2 wire connector. Tap each wire.	
	1984-92	Mark VII	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-98	Mark VIII	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Navigator	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1983-89	Town Car	Separate high beam with 2 wire connector. Tap each wire.	
	1990-94	Town Car	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Town Car	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1978-80	Versailles	Separate high beam with 2 wire connector. Tap each wire.	
Lotus		All Models		
MG		MGB		
		Midget		
		Other Models		
Maserati	1984-92	BiTurbo, Spyder	Separate high beam with 2 wire connector. Tap each wire.	
	1990-92	228, 430	Separate high beam with 2 wire connector. Tap each wire.	
Mazda	1986-94	323	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-82	626	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-85	626	Separate high beam with 2 wire connector. Tap each wire.	
	1986-92	626	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1993-97	626	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	626	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	929	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-95	929	Separate high beam with 2 wire connector. Tap each wire.	
	1984-93	B-Series Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-02	B-Series Pickup	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1977-78	GLC	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-85	GLC	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-97	Miata (MX-5)	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-00	Miata (MX-5)	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Miata (MX-5)	Separate high beam with 2 wire connector. Tap each wire.	
	1995-02	Millenia	Separate high beam with 2 wire connector. Tap each wire.	
	1989-95	MPV	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	MPV	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-95	MX-3	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-97	MX-6	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-94	Navajo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-94	Protégé	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Protégé	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Protégé 5	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1978-85	RX-7	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-91	RX-7	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-95	RX-7	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Tribute	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
Mercedes-Benz	1984-85	190	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-93	190E	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-83	240D	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-79	280E, CE	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-85	300D, CD, TD	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-91	All except SL	Single high/low with 3 wire connector. Tap the 2 outside wires.	90 300E - P-side - Remove wire harness from headlight - located upper outside corner - attach to brown & white
	1992-93	300 (D,E,CE,TE)	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-85	300SD	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985	380SE, 500SEL, SEC	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-84	380SEL	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-93	400E, 500E	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		500-Series		
		600-Series		
	1994-96	C-Class	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	C-Class	Separate high beam with 2 wire connector. Tap each wire.CB	
	1998-02	CL-Class	Separate high beam with 2 wire connector. Tap each wire.CB	

Make	Year	Model	Headlight	Notes
	1998-02	CLK-Class	Separate high beam with 2 wire connector. Tap each wire.CB	
	1994-95	E-Class	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	E-Class	Separate high beam with 2 wire connector. Tap each wire.CB	00 - D-side - disconnect harness - attach to brown and white
	2002	G-Class	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-01	M-Class	Separate high beam with 2 wire connector. Tap each wire	99 & '00 - P-side - Release harness from lamp assembly - on outside of lamp - brown & white - attach to air inlet
	2002	M-Class	Separate high beam with 2 wire connector. Tap each wire.CB	
	1994	S-Class	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	S-Class	Separate high beam with 2 wire connector. Tap each wire.CB	
	1995-96	S-Class Coupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997	S-Class Coupe	Separate high beam with 2 wire connector. Tap each wire.CB	
	1989-91	300,420,560SE, SEL	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-93	SD & SE Models	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1973-1991	SL	Separate high beam with 2 wire connector. Tap each wire.	4 sealed beam headlights - remove 2 screws holding headlight fascia - remove 2 screws holding headlight bezel - pull headlight forward and attach to the two wires - transmitter is mounted on support in front of radiator - reassemble careful not to pinch wires with headlight, bezel or fascia - check clearance of radiator grill
	1992-97	SL	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-02	SL500	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	SL600	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1998-02	SLK-Class	Separate high beam with 2 wire connector. Tap each wire.CB	
Mercury	1976-78	Bobcat	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-80	Bobcat	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-86	Capri	Separate high beam with 2 wire connector. Tap each wire.	
	1991-94	Capri	H4666	
		Comet		
	1977-87	Cougar	Separate high beam with 2 wire connector. Tap each wire.	
	1988	Cougar	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-90	Cougar	Separate high beam with 2 wire connector. Tap each wire.	
	1991-97	Cougar	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1999-02	Cougar	Separate high beam with 2 wire connector. Tap each wire.	
	1983-91	Grand Marquis	Separate high beam with 2 wire connector. Tap each wire.	
	1992-97	Grand Marquis	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Grand Marquis	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1982-83	LN7	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-85	Lynx	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-87	Lynx	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-86	Marquis	Separate high beam with 2 wire connector. Tap each wire.	
	1977	Marquis	Separate high beam with 2 wire connector. Tap each wire.	
	1978-80	Monarch	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
		Montego		
		Monterey		
	1997-02	Mountaineer	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1995-00	Mystique	Separate high beam with 2 wire connector. Tap each wire.	
	1986-91	Sable	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Sable	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1984-85	Topaz	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-94	Topaz	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-96	Tracer	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-99	Tracer	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1993-95	Villager	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	Villager	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1981-82	XR7	Separate high beam with 2 wire connector. Tap each wire.	
	1978-83	Zephyr	Separate high beam with 2 wire connector. Tap each wire.	
Merkur	1988-89	Scorpio	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-89	XR4Ti	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Mini	2002-04	All Models	Headlights are part of the hood. Attach TX behind headlight and tap Brown (-) and Yellow with green trace or blue trace depending on which side.	
Mitsubishi	1991-93	3000GT	H4666	

Make	Year	Model	Headlight	Notes
	1994-99	3000GT	Separate high beam with 2 wire connector. Tap each wire.	
	1983-87	Cordia	Separate high beam with 2 wire connector. Tap each wire.	
	1988	Cordia	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-02	Diamante	Separate high beam with 2 wire connector. Tap each wire.	
	1990-91	Eclipse	H4666	
	1992-99	Eclipse, Spyder	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	Eclipse, Spyder	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-94	Expo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-96	Expo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Galant	Separate high beam with 2 wire connector. Tap each wire.	
	1988-98	Galant	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	Galant	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Lancer	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1992-96	Mighty Max	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Mirage	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988	Mirage	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-92	Mirage	Separate high beam with 2 wire connector. Tap each wire.	
	1993-96	Mirage	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-02	Mirage	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-87	Montero	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-91	Montero	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1992-97	Montero	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-02	Montero	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-99	Montero Sport	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Montero Sport	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1984-87	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	Pickup	Separate high beam with 2 wire connector. Tap each wire.	
	1988-93	Precis	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-90	Sigma	Separate high beam with 2 wire connector. Tap each wire.	
	1984-88	Starion	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-85	Tredia	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-88	Tredia	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	Van, Wagon	Separate high beam with 2 wire connector. Tap each wire.	
Nissan	1977-79	200SX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-84	200SX	Separate high beam with 2 wire connector. Tap each wire.	
	1985-88	200SX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-97	200SX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998	200SX	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1978-80	210	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-82	210	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1989-94	240SX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-98	240SX	Separate high beam with 2 wire connector. Tap each wire.	
	1979-83	280ZX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-86	300ZX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-89	300ZX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-96	300ZX	Separate high beam with 2 wire connector. Tap each wire.	
	1979-80	310	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-82	310	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		350Z		
	1980-81	510	Separate high beam with 2 wire connector. Tap each wire.	
	1980-81	720	Separate high beam with 2 wire connector. Tap each wire.	
	1979-84	810	Separate high beam with 2 wire connector. Tap each wire.	
	1993-97	Altima	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-01	Altima	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2002	Altima	Separate high beam with 2 wire connector. Tap each wire.	
	1990-91	Axxess	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1976-78	F10	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-02	Frontier	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984	Maxima	Separate high beam with 2 wire connector. Tap each wire.	
	1985-99	Maxima	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-01	Maxima	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	2002	Maxima	Separate high beam with 2 wire connector. Tap each wire.	
	1991-92	NX1600, NX2000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993	NX1600, NX2000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-99	Pathfinder	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Pathfinder	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-86	Pickup	Separate high beam with 2 wire connector. Tap each wire.	
	1987-97	Pickup w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-94	Pickup w/Composite	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-90	Pulsar	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-95	Quest	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	Quest	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	04 - D-side
	1982-84	Sentra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-92	Sentra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	Sentra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-99	Sentra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Sentra	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1982-84	Stanza	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-92	Stanza	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-89	Vanette	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000	Xterra	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	2001-02	Xterra	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
Oldsmobile	1992-98	Achieva	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-02	Alero	Separate high beam with 2 wire connector. Tap each wire.	
	1995-99	Aurora	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	Aurora	Separate high beam with 2 wire connector. Tap each wire.	
	1991-94	Bravada	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	Bravada	Separate high beam with 2 wire connector. Tap each wire.	
	1985-86	Calais	Separate high beam with 2 wire connector. Tap each wire.	
	1987-88	Calais	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-84	Ciera	Separate high beam with 2 wire connector. Tap each wire.	
	1985-90	Custom Cruiser	Separate high beam with 2 wire connector. Tap each wire.	
	1991-92	Custom Cruiser	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-80	Cutlass *	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-84	Cutlass	Separate high beam with 2 wire connector. Tap each wire.	
	1997-99	Cutlass	Separate high beam with 2 wire connector. Tap each wire.	
	1989-91	Cutlass Calais	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Cutlass Ciera	Separate high beam with 2 wire connector. Tap each wire.	
	1987-96	Cutlass Ciera	Separate high beam with 2 wire connector. Tap each wire.	
	1985-86	Cutless Cruiser	Separate high beam with 2 wire connector. Tap each wire.	
	1988-95	Cutless Cruiser	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1976	Cutlass F85	Separate high beam with 2 wire connector. Tap each wire.	
	1988	Cutlass (FWD)	Separate high beam with 2 wire connector. Tap each wire.	
	1985-86	Cutlass Salon	Separate high beam with 2 wire connector. Tap each wire.	
	1987	Cutlass Salon *	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-86	Cutlass Supreme	Separate high beam with 2 wire connector. Tap each wire.	
	1987	Cutlass Supreme *	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-91	Cutlass Supreme	Separate high beam with 2 wire connector. Tap each wire.	
	1988	Cutlass Supreme Classic Coupe *	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988	Cutlass Supreme Classic Sedan	Separate high beam with 2 wire connector. Tap each wire.	
	1992-97	Cutlass Supreme 2-Door	Separate high beam with 2 wire connector. Tap each wire.	
	1992-97	Cutlass Supreme 4-Door	Separate high beam with 2 wire connector. Tap each wire.	
	1976-86	Delta 88, 98	Separate high beam with 2 wire connector. Tap each wire.	
	1987	Delta 88	Separate high beam with 2 wire connector. Tap each wire.	
	1987-88	Delta 88	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		442		
	1988-89	Eighty-Eight	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-99	Eighty-Eight	Separate high beam with 2 wire connector. Tap each wire.	
	1982	Firenza	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-87	Firenza	Separate high beam with 2 wire connector. Tap each wire.	
	1988	Firenza	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	Intrigue	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1996-99	LSS	Separate high beam with 2 wire connector. Tap each wire.	
	1987	Ninety-Eight	Separate high beam with 2 wire connector. Tap each wire.	
	1992-96	Ninety-Eight	Separate high beam with 2 wire connector. Tap each wire.	
	1973-79	Omega	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-84	Omega	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-98	Regency	Separate high beam with 2 wire connector. Tap each wire.	
	1990-91	Regency 98	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	Royale 88	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-96	Silhouette	Separate high beam with 2 wire connector. Tap each wire.	
	1997-02	Silhouette	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1975-80	Starfire	Separate high beam with 2 wire connector. Tap each wire.	
	1976-85	Toronado	Separate high beam with 2 wire connector. Tap each wire.	
	1991	Toronado	Separate high beam with 2 wire connector. Tap each wire.	
	1991	Trofeo	Separate high beam with 2 wire connector. Tap each wire.	
	1992	Tornado, Tornado Trofeo	H4701	
	1987	Touring Sedan	Separate high beam with 2 wire connector. Tap each wire.	
	1988-90	Touring Sedan	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Opel	1972-78	All exc. Manta	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Peugeot	1989-91	405	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-79	504	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1986-91	505, 505 Turbo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-83	604	Separate high beam with 2 wire connector. Tap each wire.	
Plymouth	1989-95	Acclaim	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1976-80	Arrow	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Barracuda		
	1996-00	Breeze	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1985-88	Caravelle	Separate high beam with 2 wire connector. Tap each wire.	
	1981-88	Colt	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989	Colt	Separate high beam with 2 wire connector. Tap each wire.	
	1993-94	Colt	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992	Colt H/Back, Canada	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992	Colt H/Back exc. Canada	Separate high beam with 2 wire connector. Tap each wire.	
	1990-91	Colt Sedan	Separate high beam with 2 wire connector. Tap each wire.	
	1987-88	Colt Vista	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991	Colt Vista	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-94	Colt Vista	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-90	Colt Wagon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	Duster	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-78	Fury	Separate high beam with 2 wire connector. Tap each wire.	
	1980-89	Gran Fury	Separate high beam with 2 wire connector. Tap each wire.	
		Grand Voyager		

Make	Year	Model	Headlight	Notes
		GTX		
	1978-84	Horizon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Horizon 2-Door	Separate high beam with 2 wire connector. Tap each wire.	
	1985-87	Horizon 4-Door	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-89	Horizon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-91	Laser	H4666	
	1992-94	Laser	Separate high beam with 2 wire connector. Tap each wire.	
	1995-01	Neon	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1997-01	Prowler	Separate high beam with 2 wire connector. Tap each wire.	
	1981-89	Reliant	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Road Runner		
	1978-83	Sapporo	Separate high beam with 2 wire connector. Tap each wire.	
		Satellite		
	1987-88	Sundance	H4666	
	1989-94	Sundance	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984	Turismo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Turismo 2-Door	Separate high beam with 2 wire connector. Tap each wire.	
	1985-87	Turismo 4-Door	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1976-79	Volare	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980	Volare	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-87	Voyager	Separate high beam with 2 wire connector. Tap each wire.	
	1987-95	Voyager	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1996-00	Voyager	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	97 - P-side - Black & red - attach to foam covered high pressure line under hood
Pontiac	1986-87	1000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-86	6000	Separate high beam with 2 wire connector. Tap each wire.	
	1987-88	6000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	6000	Separate high beam with 2 wire connector. Tap each wire.	
	1986-89	6000 STE	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978	Astre	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	Aztek	Separate high beam with 2 wire connector. Tap each wire.	
	1975-76	Bonneville	Separate high beam with 2 wire connector. Tap each wire.	
	1981	Bonneville	Separate high beam with 2 wire connector. Tap each wire.	
	1982	Bonneville	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-86	Bonneville	Separate high beam with 2 wire connector. Tap each wire.	
	1987-02	Bonneville	Separate high beam with 2 wire connector. Tap each wire.	
	1981	Catalina	Separate high beam with 2 wire connector. Tap each wire.	
	1984-88	Fiero	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1977-82	Firebird	Separate high beam with 2 wire connector. Tap each wire.	
	1983-90	Firebird	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1991-97	Firebird	H4666	
	1998-02	Firebird	H4701	
	1985-89	Grand Am	Separate high beam with 2 wire connector. Tap each wire.	
	1987-89	Grand Am	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1990-98	Grand Am	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	Grand Am	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1976-77	Grand Le Mans	Separate high beam with 2 wire connector. Tap each wire.	
	1976-87	Grand Prix	Separate high beam with 2 wire connector. Tap each wire.	
	1991-96	Grand Prix w/Sealed Beam	Separate high beam with 2 wire connector. Tap each wire.	
	1988-96	Grand Prix w/Composite	Separate high beam with 2 wire connector. Tap each wire.	
	1997-02	Grand Prix	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
		GTO		
	1982	J2000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-84	J2000	Separate high beam with 2 wire connector. Tap each wire.	
	1978-81	Le Mans	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-93	Le Mans	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-02	Montana	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-86	Parisienne	Separate high beam with 2 wire connector. Tap each wire.	
	1978-84	Phoenix	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-88	Safari	Separate high beam with 2 wire connector. Tap each wire.	Not Pontiac
	1989	Safari	Separate high beam with 2 wire connector. Tap each wire.	
	1976-88	Sunbird	Separate high beam with 2 wire connector. Tap each wire.	
	1991-94	Sunbird w/Sealed Beam	H4701	
	1989-94	Sunbird w/Composite	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1995-02	Sunfire	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1982-84	T1000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Tempest		
		Trans Am		
	1990-96	Trans Sport	Separate high beam with 2 wire connector. Tap each wire.	
	1997-98	Trans Sport	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Porsche		356		
	1969-86	911	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-94	911	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-2002	911	Separate high beam with 2 wire connector. Tap each wire	
	1965-69	912		
		912E		
	1970-76	914		
	1977-88	924	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-86	928	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-95	928	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		930		
	1982-91	944	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-94	968	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995	968	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-02	996	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1997-02	Boxster	Separate high beam with 2 wire connector. Tap each wire.	00 - P-side - Remove headlight assembly per owners manual - release harness by pulling down on retaining clip - attach to white & larger brown wire - splice extra 20 gage wire and attach transmitter to plastic brace under front of headlight hole - route wires under bracket
		Cayenne		
Renault	1981-84	18i	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-80	All Models	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1983-85	Alliance	Separate high beam with 2 wire connector. Tap each wire.	
	1987	Alliance	H4666	
	1985	Encore	Separate high beam with 2 wire connector. Tap each wire.	
	1982-85	Fuego	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987	GTA	H4666	
	1978	GTL	Separate high beam with 2 wire connector. Tap each wire.	
	1978	R5	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-84	R5, Le Car	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Rolls-Royce		All Models		
Saab	1999-02	9-3	Single high/low with 3 wire connector. Tap the 2 outside wires.	03 - P-side - Remove air intake and back of headlight for easier access - release harness by sliding retaining clip up and pulling harness free - black & white wires
	1999-02	9-5	Separate high beam with 2 wire connector. Tap each wire.	
	1981-86	900	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1987-93	900	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-98	900	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987-92	9000	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	9000CD	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	9000CS	Separate high beam with 2 wire connector. Tap each wire.	
	1995-98	9000CD, CS	Separate high beam with 2 wire connector. Tap each wire.	
Saturn	1991-92	Coupe	H4666	
	1991-02	Sedan	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	L Series	Separate high beam with 2 wire connector. Tap each wire.	
	1992	SC Coupe	H4666	
	1993-02	SC1	Separate high beam with 2 wire connector. Tap each wire.	
	1993-96	SC2	H4666	
	1997-02	SC2	Separate high beam with 2 wire connector. Tap each wire.	
	1992-02	SL, SL1, SL2	Separate high beam with 2 wire connector. Tap each wire.	
	1993	SL3	H4666	
	1993-01	SW1, SW2	Separate high beam with 2 wire connector. Tap each wire.	
	2002	Vue	Separate high beam with 2 wire connector. Tap each wire.	
Sterling	1989-91	827S, SL, SLI, SI	Separate high beam with 2 wire connector. Tap each wire.	
Subaru	1982-87	Brat	Separate high beam with 2 wire connector. Tap each wire.	
	1976-81	DL	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-84	DL	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1985-89	DL	Separate high beam with 2 wire connector. Tap each wire.	
	1982-89	GL	Separate high beam with 2 wire connector. Tap each wire.	
	1985-89	GL Exc. H/back	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-02	Forester	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2004	Forester	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1993-01	Impreza	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Impreza	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1987-88	Justy	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-94	Justy	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-91	Legacy	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-97	Legacy	Single high/low with 3 wire connector. Tap the 2 outside wires.	97 Legacy Outback - D - side - peel back rubber boot and attach TX to 2 outside wires - red & purple - mount to hi pressure line next to battery
	1998-02	Legacy	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	2000-02	Legacy Outback	Separate high beam with 2 wire connector. Tap each wire.	
	1990-94	Loyale	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-89	RX	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979	Sedan	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-87	STD	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-97	SVX	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1985-91	XT	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Suzuki	1995-02	Esteem	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-02	Grand Vitara	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-95	Samurai	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-98	Sidekick	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-94	Swift	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-97	Swift	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-01	Swift	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
	1999-02	Vitara	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-98	X-90	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Toyota	1988-91	4Runner	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-95	4Runner	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-02	4Runner	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Avalon	Separate high beam with 2 wire connector. Tap each wire.	
	1983-84	Camry	Separate high beam with 2 wire connector. Tap each wire.	
	1985-91	Camry	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-96	Camry	Separate high beam with 2 wire connector. Tap each wire.	
	1997-99	Camry	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Camry	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1980-81	Celica	Separate high beam with 2 wire connector. Tap each wire.	
	1982-93	Celica	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-02	Celica	Separate high beam with 2 wire connector. Tap each wire.	
	1979-82	Corona	Separate high beam with 2 wire connector. Tap each wire.	
	1969-78	Corolla	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-85	Corolla	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980	Corolla Coupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-92	Corolla Coupe	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1987	Corolla RWD	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992	Corolla SR5, GTS	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-92	Corolla	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-97	Corolla	Separate high beam with 2 wire connector. Tap each wire.	
	1998-00	Corolla	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Corolla	Separate high beam with 2 wire connector. Tap each wire.	
	1977-78	Cressida	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980	Cressida	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1981-84	Cressida	Separate high beam with 2 wire connector. Tap each wire.	
	1985-92	Cressida	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Echo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Highlander	Separate high beam with 2 wire connector. Tap each wire.	
	1979-87	LandCruiser	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1988-90	LandCruiser	Separate high beam with 2 wire connector. Tap each wire.	
	1991-02	LandCruiser	Separate high beam with 2 wire connector. Tap each wire.	
	1986-95	MR2	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	MR2 Spyder	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-98	Paseo	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979-81	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-95	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-93	Previa	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-97	Previa	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Prius	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1996-97	RAV4	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1998-00	RAV4	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	RAV4	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2001-02	Sequoia	Single high/low with 3 wire connector. Tap the 2 outside wires.	04 - P-side - Mount TX to radiator bracket and feed wires back to engine compartment - outside wires
	1998-02	Sienna	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-01	Solara	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Solara	Separate high beam with 2 wire connector. Tap each wire.	
	1981-83	Starlet	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1979	Supra	Separate high beam with 2 wire connector. Tap each wire.	
	1981-93	Supra	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1994-98	Supra	Separate high beam with 2 wire connector. Tap each wire.	
	1993-98	T-100 Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-97	Tacoma w/Sealed Beam	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-02	Tacoma w/Composite	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2000-02	Tundra	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-87	Tercel	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-94	Tercel w/Sealed Beam	H4666	
	1987-96	Tercel w/Composite	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997	Tercel	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999	Tercel	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984-91	Van	Separate high beam with 2 wire connector. Tap each wire.	
Triumph	1973-80	All	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Volkswagen	1971-79	Beetle	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-99	Cabrio	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-01	Cabrio	Separate high beam with 2 wire connector. Tap each wire.	
	2002	Cabrio	Separate high beam with 2 wire connector. Tap each wire.	
	1985-93	Cabriolet	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1990-94	Corrado	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993	Eurovan	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-02	Eurovan	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1989-91	Fox	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-93	Fox	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	Golf	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1988-99	Golf w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-99	Golf w/4 Headlights	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	Golf, GTI	Separate high beam with 2 wire connector. Tap each wire.	
	1985-92	GTI	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-84	Jetta	Separate high beam with 2 wire connector. Tap each wire.	
	1985-98	Jetta	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1997-99	Jetta	Separate high beam with 2 wire connector. Tap each wire.	
	1999	Jetta	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1999-02	Jetta	Single high/low with 3 wire connector. Looking at the light from the front of the vehicle, tap the left and the middle wires.	
		Karman Ghia		
		New Beetle		
	1990-94	Passat	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1995-98	Passat	Separate high beam with 2 wire connector. Tap each wire.	
	1998-01	Passat	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	2002	Passat	Separate high beam with 2 wire connector. Tap each wire.	
	1980-83	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1984	Pickup	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-86	Quantum	Separate high beam with 2 wire connector. Tap each wire.	

Make	Year	Model	Headlight	Notes
	1987-88	Quantum	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1982-88	Scirocco	Separate high beam with 2 wire connector. Tap each wire.	
	1979-84	Rabbit	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1980-84	Rabbit Convertible	Single high/low with 3 wire connector. Tap the 2 outside wires.	
		Thing		
	1981-85	Vanagon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-92	Vanagon	Single high/low with 3 wire connector. Tap the 2 outside wires.	
Volvo	1979	242	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1986-93	240	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1978-79	262C	Separate high beam with 2 wire connector. Tap each wire.	
	1978-79	264, 265	Separate high beam with 2 wire connector. Tap each wire.	
	1985-89	740	Separate high beam with 2 wire connector. Tap each wire.	
	1990-92	740	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1985-87	760	Separate high beam with 2 wire connector. Tap each wire.	
	1988-90	760	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1989-91	780	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1993-94	850 w/2 Headlights	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1994-97	850 w/4 Headlights	Separate high beam with 2 wire connector. Tap each wire.	95 - Disconnect harness by squeezing wire retaining bar and pulling plug free - black & blue wires
	1991-95	940	Single high/low with 3 wire connector. Tap the 2 outside wires.	
	1992-95	960	Single high/low with 3 wire connector. Tap the 2 outside wires.	

Make	Year	Model	Headlight	Notes
	1996-97	960	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	C70 Convertible	Separate high beam with 2 wire connector. Tap each wire.	
	1998-02	C70 Coupe	Separate high beam with 2 wire connector. Tap each wire.	
	1980	GLE, Coupe	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	S40	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	S60	Separate high beam with 2 wire connector. Tap each wire.	02 - P-side - disconnect harness from light assembly - tap ? & ? - mount above light to wire harness
	1998-00	S70	Separate high beam with 2 wire connector. Tap each wire.	
	1999-02	S80	Separate high beam with 2 wire connector. Tap each wire.	
	1998	S90	Separate high beam with 2 wire connector. Tap each wire.	
	2000-02	V40	Separate high beam with 2 wire connector. Tap each wire.	
	1997	V70 XC		P-side - disconnect harness from light assembly - tap black & blue - mount above light, below crossbar
	1998-00	V70	Separate high beam with 2 wire connector. Tap each wire.	
	2001-02	V70	Separate high beam with 2 wire connector. Tap each wire.	
	1998	V90	Separate high beam with 2 wire connector. Tap each wire.	
		XC		
	1981-85	All	Separate high beam with 2 wire connector. Tap each wire.	
Yugo	1986-90	1100cc	Single high/low with 3 wire connector. Tap the 2 outside wires.	